



EXHAUST FAN

OPERATING INSTRUCTIONS



DWELL
AIR

VENTILATION FAN
(INLINE FAN)




DAIF 100
DAIF 150

SPECIFICATIONS


Model	SIZE	Rated Voltage	Rated Frequency	Rated Power	Air Volume	Noise
DAIF 100	Φ100	220/240V	50/60Hz	14W	80m ³ /h	33dB
DAIF 125	Φ120	220/240V	50/60Hz	17W	150m ³ /h	35dB
DAIF 150	Φ150	220/240V	50/60Hz	22W	250m ³ /h	37dB

PRODUCT DIMENSION





MODEL	A (mm)	B (mm)	C (mm)	D (mm)
DAIF 100	Ø97.8	87	150	114
DAIF 125	Ø 117	102	180	136
DAIF 150	Ø 146	128	222.5	167.2

WIRING DIAGRAM



APPLICATION



Start

- *Please confirm before start:
- *Wiring is correct, and the equipment's wire connection is firm.
- *Electrical safety device is connected correctly and adjusted to proper position.
- *The wire and wire joints are insulative and water resistant.
- *The vane wheel's rotation is right.
- *There is no abnormal vibration.
- *If the wire installation device trips, please cut off the power supply.
Before start later, please check all installation.

Maintenance

- *Before maintenance of the blower, though the blower's switch is off, please cut off the main power supply in case of others' delivery of electricity by mistake.
- *Check the equipment and its working environment regularly, in case of too much dust stocked on vane wheel, protective screening, which brings danger or cause the product's working life.
- *Please be greatly careful while washing, in case of destroying vane wheel's balance.